Portable Safe with a Combination Lock MSZ 200







for ID cards, cash, smartphones etc.

offers protection when travelling, in the car and at the office

with a detachable steel cable




OPERATING MANUAL









Resetting the password

Turn the number dials to the position **0-0-0-0** (original password) and open the lid of the Mobile Safe. Now choose a 4-digit combination number. Jot down this new combination number and keep it somewhere safe.

1. + 2. Press the RESET lever in the Mobile Safe from position A to B and then enter your new 4-digit combination number.

3. After entering the new number, press the RESET lever back into the starting position A again.

Cleaning/maintenance

Slight soiling of the Mobile Safe can be removed with a damp cloth.



Disposal

Help to protect the environment and dispose of the product and the packaging materials in accordance with the local regulations. © Copyright

Reproduction or duplication (even excerpts thereof) is forbidden without the consent of: BASI GmbH Konstantinstraße 387 41238 Mönchengladbach Germany

2023

This publication, including all its parts, is protected by copyright.

Any use outside the narrow limits of copyright law without the consent of BASI GmbH is not allowed and is liable to prosecution.

> This applies in particular to duplications, translations, microfilming and importing and processing in electronic systems.

> > BASI GmbH Konstantinstraße 387 41238 Mönchengladbach Germany

General notes

Intended use

The Mobile Safe with the combination lock is an ideal place to keep ID cards, cash, smartphones, car keys, mobile phones or any other small objects that you want to protect from theft at the beach, pool, hotel etc. The cable can be used to secure the portable safe to a stationary object.

Follow the instructions in this manual on how to use the portable safe correctly. Keep the manual in case you want to change the combination number at a later date.




Warnings: No hazards are to be expected, if the device is used correctly and in accordance with the instructions. Small parts and

packaging materials can be swallowed by children and lead to choking! Make sure that small parts and packaging materials do not get into the hands of children. Dispose of the packaging material immediately.

The portable safe has the following product properties:

- · compact and light
- settable 4-digit number combination (10,000 combinations)
- weather-resistant
- housing made of durable ABS material
- colour: black
- detachable steel cable in a vinyl sheath (L = 540 mm / diameter = 5 mm) to attach to a stationary object
- waterproof tested to IPX5
- external box size: 240 x 140 x 85 mm
- inner space size: 205 x 105 x 40 mm





The manufacturer expressly reserves the right to make technical changes.

Disclaimer

The manufacturer accepts no liability for damage or injury resulting from incorrect handling.

Scope of delivery

Check that the delivery is complete:

- 1x mobile safe with a combination lock
- 1x operating manual